

# **INVISIBLE PATTERNS**

## **VENTURESHIELD FITTING INSTRUCTIONS FOR MOUNTAIN BIKES**

### **Preparation:**

Installation should always take place in a warm (60-90 degrees F.), dry location. The area must be enclosed as sunlight and wind will complicate installation.

The bike's surface must be thoroughly cleaned and rinsed with running water. All bugs, road tar, dirt and other contaminants must be removed before the bike can be dried and ready for installation, we recommend using methylated spirits to wipe the panels and remove wax residue.

You will require 2 spray bottles. One with soapy solution(water and washing up liquid) and one with clean fresh water.

- 2" Masking tape(to make templates)
- Pencil or pen
- Scalpel or scissors.

### **Templating**

There is no set way to do this but we have found the most accurate way to do it, is to make some templates from which you can then cut from the sheet of film.

Apply the masking tape to the area of the bike you wish to protect. Pencil out the exact shape you want onto the masking tape. Now peel off the masking tape and apply it to the the backing cover on the sheet of film. From here you can now accurately cut your desired shape from the sheet of film (use a scalpel for intricate shapes). When you have all your required shapes please follow the step by step fitting instructions below:

### **ALWAYS READ THESE INSTRUCTIONS FIRST TO GET ACCUSTOMED TO THE INSTALLATION**

- Step 1: Spray the area to be coated with the soapy solution.
- Step 2: Remove the appropriate piece of film to be applied from the backing sheet spraying the sticky side with soapy solution as it is removed.
- Step 3: Lay it onto the bike and find a good point to start the installation.
- Step 4: Using the rubber squeegee supplied, remove the water from under the film and work across the piece of film (if you need to, the film will stretch to remove fingers etc., just lay your palm on the film and stretch while using the squeegee in the other hand.)
- Step 5: If there are fingers that keep coming back, use the fresh water solution and spray into the finger and squeegee again. You can also use the heat from your hands to press the section and start the adhesive process. (It is only the soap in the spray bottle stopping the tack of the film from sticking to the bike.)
- NOTE: If you do see small bubbles under the film either use the squeegee to press out the bubbles or remove the film whilst spraying with the soapy solution as you go and start again. (If there are sections that will not fully stick on the edges, leave the film for 5 minutes then press down again.)
- Step 6: Sit back and be amazed, your bike is now protected!!!

**Help Line:**  
**07880 730 881 (Normal Working Hours)**